

Standard Guardrail

Bolt-In Base Plate Installation

Available for All Heights

- 1. Layout Guardrail in appropriate location on concrete**
- 2. Using a 3/4" drill-bit; drill holes with a hammer drill**
- 3. Secure base plates with [4] 3/4" x 6 1/4" anchors***
- 4. Your Guardrail is now installed**

***epoxy anchors can be used as well**

